

1. System Contents

A Smartvue IP video system includes one or more Smartvue cameras and a Smartvue Digital Video Manager (DVM). The complete systems includes power cables, a standard network cable (gray), a crossover network cable (red), the Smartvue User Guide, camera shelf stand, wall mounting kit, drop ceiling mounting kit, and a Setup CD-ROM

2. Camera Setup

Slide the Smartvue camera into the shelf stand, then place it on any bookshelf or flat surface. Remove the shelf stand when using the drop ceiling or wall mounting kit. Plug the gray power cable into the camera (A). The camera status light on the front of the camera will illuminate.

Although the wireless range of a Smartvue camera will usually cover the entire floor of a building or entire multi-floor home and may reach thousands of feet, environmental factors such as reinforced metal walls and the number of cameras per DVM will affect its range.

3. Digital Video Manager (DVM) Setup

Place the DVM on a flat surface and plug the power cable into back of the DVM (A). If connecting to a network, use the GRAY network cable and plug one end into the DVM (B) and the other end to your network. Turn on the DVM by pressing and releasing the power button (C) only once. The blue light in the logo on the front of the DVM will illuminate.

Important Notes: To turn off the DVM, press and release the power button only once. The shutdown may take a minute or more. If connecting directly to a PC, use the RED crossover cable and before connecting, change the IP address of your PC to 192.168.1.110 (the default DVM IP is 192.168.1.100).

4. Viewing Video

Insert the Smartvue CD-ROM into your Windows PC and follow the step by step instructions. During the setup, the DVM Finder application (which finds the IP address of your DVM on the network) will automatically start. Click on the SEARCH button. The IP address of your DVM will be displayed, click on it, then click CREATE ICON. This will put an icon for the DVM on your desktop to make it easy to access. Close DVM Finder by clicking on the X in the upper right corner.

Double click the DVM icon on your desktop. A web browser will open the DVM log-in screen. Enter the username "admin" and the password "admin" (you can change this later). Click SETTINGS in the top menu. If you do not see camera preview in the left window, click the option ADD CAMERAS, then click the ADD CAMERAS button. The DVM will search for and display a list of available cameras (either wireless or wired). Select any camera by clicking the checkbox next to a camera, then click the ADD CAMERAS button. After the cameras have been added, click LIVE VIDEO in the top menu. Click on any preview image in the list on the left to view video from that camera. For full screen or other views, click on any one of the view options in the upper right corner.

Smartvue requires a Windows or Apple PC with 1.2GHz or higher processor and Internet Explorer, Netscape, Safari, or Firefox web browser. For more about the other features including recording, motion detection, alerts, and remote PC or cell phone access, please see the User Guide.

